



- Pour Shear Key flush to Working Point (W.P.). 1/2" bituminous fiber shall be installed at the interface of the beam and shear key. Shear Key concrete to be poured after beams are placed. Care shall be taken to keep concrete from flowing under the beams.

Fig. 4-35